


5353 DEMOLITION HAMMER 11E PRO (OLD)



Demolition Hammer 11E (Old)

S.NO	Part No.	Spare Part Name	Qty	S.NO	Part No.	Spare Part Name	Qty
1	11E-001	Front Cap	1	50	11E-050	motor housing	1
2	11E-002	Slippage Clamp	1	51	11E-051	screw	2
3	11E-003	steel wire retainer ring	1	52	11E-052	stator	1
4	11E-004	washer30*48.5*3	1	53	11E-053	resistance oil ring	1
5	11E-005	cushion washer	1	54	11E-054	stell slleeve	1
6	11E-006	Clamp sleeve	1	55	11E-055	armature	1
7	11E-007	lock key	2	56	11E-056	bearing seat	1
8	11E-008	clamp ring	1	57	11E-057	o ring	1
9	11E-009	spring	1	58	11E-058	bearing	1
10	11E-010	lock ring	1	59	11E-059	steel wire retainer ring	1
11	11E-011	rotate sleeve	1	60	11E-060	brush holder seat	1
12	11E-012	screw	4	61	11E-061	extension spring	2
14	11E-014	steel ball	8	62	11E-062	screw	3
15	11E-015	head	1	63	11E-063	carbon brush	2
16	11E-016	o ring	1	64	11E-064	brush holder	2
17	11E-017	spring retailing ring	2	65	11E-065	spring	1
18	11E-018	oil seal	1	66	11E-066	baffle	1
19	11E-019	rotaty sleeve	1	67	11E-067	rear cover	1
20	11E-020	o ring	1	68	11E-068	fixed nut	1
21	11E-021	striker sleeve	1	69	11E-069	screw	5
22	11E-022	o ring	1	70	11E-070	protective cover	1
23	11E-023	guider ring	1	71	11E-071	pilot light	1
24	11E-024	fixed seat	1	72	11E-072	speed controller	1
25	11E-025	gearbox cover	1	73	11E-073	side cover	1
26	11E-026	striker	1	74	11E-074	damping sleeve	1
27	11E-027	o ring	2	75	11E-075	damping block	1
28	11E-028	cylinder	1	76	11E-076	flat washer	2
29	11E-029	guider sleeve	1	77	11E-077	screw	2
30	11E-030	spring	1	78	11E-078	spring washer	2
31	11E-031	piston pin	1	79	11E-079	screw	4
32	11E-032	piston	1	80	11E-080	left handle	1
33	11E-033	lever	1	81	11E-081	switch	1
34	11E-034	gear box	1	82	11E-082	cord clamp	1
35	11E-035	eccentric shaft	1	83	11E-083	cord sleeve	1
36	11E-036	washer	1	84	11E-084	power cord	1
37	11E-037	needle bearing	1	85	11E-085	screw	1
38	11E-038	oil cover	1	86	11E-086	right handle	1
39	11E-039	o ring	1	87	11E-087	screw	5
40	11E-040	wool ring	3	88	11E-088	screw bolt	1
41	11E-041	flat washer	1	89	11E-089	clamping block	2
42	11E-042	screw	1	90	11E-090	fastening belt	1
43	11E-043	screw	4	91	11E-091	handle clip	2
44	11E-044	gearcase cover	1	92	11E-092	wheel	1
45	11E-045	o ring	1	93	11E-093	M8 nut	1
46	11E-046	screw	4	94	11E-094	wheel cover	1
47	11E-047	needle bearing	1	95	11E-095	side handle	1
48	11E-048	spring retailing ring	1	96	11E-096	washer	1
49	11E-049	oil seal	1				