




2835 DEMOLITION HAMMER 1200W



RISHAB INTERNATIONAL

2835 Demolition Hammer 7 KG

S. No.	Drawing No.	Part No	Description
1	9	91001210	O Ring
2	9	91001210	O Ring
3	10	91001220	Assault Block
4	11	91001230	Assault Block Washer
5	12	91001240	Rubber Washer
6	13	91001250	Cylinder head
7	14	91001260	O Ring
8	19	91001310	Front Placket
9	20	91001320	O Ring
10	20	91001320	O Ring
11	21	91001330	Hammer
12	22	91001340	O Ring
13	22	91001340	O Ring
14	23	91001350	Cylinder Ring
15	24	91001360	Piston Pin
16	25	91001370	Piston
17	28	91001400	Gearbox
18	30	91001420	Oil Cover flange
19	34	91001460	Eccentric Shaft
20	38	91001500	Decorative cover
21	39	91001510	Damping Spring
22	40	91001520	Damping Spring Sleeve
23	41	91001530	Damping Spring Pin
24	42	91001540	Damping Spring Seat
25	44	91001560	Damping Sleeve
26	45	91001570	Oil Seal
27	46	91001580	Gear distance Range Ring
28	48	91001600	Gear
29	50	91001620	O Ring
30	51	91001630	Medial Flange
31	52	91001640	Threaded ring
32	54	91001660	O Ring
33	55	91001670	Dust proof Washer
34	56	91001680	Armature Assy.
35	57	91001690	Dust Protector
36	59	91001710	Wind Deflector
37	63	91001750	Motor Shell
38	65	91001770	Brush Holder
39	66	91001780	Carbon Brush
40	67	91001790	Spring
41	69	91001810	Rear Cover
42	72	91001840	Switch trigger
43	73	91001850	Switch trigger Spring
44	74	91001860	Capacitor
45	75	91001870	Switch (with self-locking)
46	76	91001880	Cord Clamp
47	77	91001890	electric cablesleeve
48	78	91001900	electric cable
49	200 (26-27)	91001980	Connecting Rod Assy.
50	201 (71-79)	91001990	Handle Assy.
51	202 (1-8)	91002950	Cylinder Head Assy.1-8
52	203 (9-19)	91002960	Cylinder Assy.
53	204 (29-33)	91002970	Oil Seal cover Assy.
54	205 (59-69)	91002980	Coil Assy.
55	206 (82-85)	91003010	Auxiliary Handle Assy.