




2895 Demolition Hammer/1600W



RISHAB INTERNATIONAL

2895 DEMOLITION HAMMER

S No.	Drawing No.	Part No	Description
1	8	91002070	Iron-head
2	10	91002090	Shockproof ring
3	11	91002100	o ring
4	12	91002110	Drill handle sleeve
5	13	91002120	Rubber ring for opening sleeve
6	14	91002130	opening sleeve
7	15	91002140	Open sleeve washer
8	16	91002150	Shockproof
9	17	91002160	Front Placket (NECK)
10	18	91002170	Socket Head Cap Screw
11	19	91002180	o ring
12	20	91002190	Cylinder
13	21	91002200	Piston double lip ring (L RING)
14	22	91002210	Piston
15	23	91002220	Pin
16	26	91002250	Crankshaft Flange
17	27	91002260	Socket Head Cap Screw
18	28	91002270	Bearing
19	29	91002280	Retainer Ring
20	30	91002290	Large helical gear
21	31	91002300	Large gear distance ring
22	32	91002310	Socket Head Cap Screw
23	33	91002320	Spring Washer
24	34	91002330	Bearing (6205) Clamp
25	35	91002340	Bearing (6205RS)
26	36	91002350	Key
27	37	91002360	Crankshaft
28	38	91002370	o ring
29	39	91002380	Tank
30	40	91002390	Oil Rope
31	41	91002400	Fuel Tank Cap gasket
32	42	91002410	Fuel Tank Cap
33	43	91002420	Fuel tank port o ring
34	44	91002430	Fuel tank port Assy.
35	45	91002440	Tapping Screw
36	46	91002450	Bearing (6201RS)
37	47	91002460	Helical gear
38	48	91002470	Bearing (6001RS)
39	49	91002480	Front Cover
40	50	91002490	Dust Guard
41	51	91002500	o ring
42	52	91002510	Reduction gearbox
43	53	91002520	Bearing (6203RS)
44	54	91002530	Bearing Washer
45	55	91002540	Armature
46	56	91002550	Bearing (6201RS)
47	57	91002560	Tapping Screw
48	58	91002570	Wind Deflector
49	59	91002580	Coil
50	60	91002590	Plastic Shell
51	61	91002600	Brush Holder
52	62	91002610	Carbon Brush (set)
53	63	91002620	Carbon Brush Wave Washer
54	64	91002630	Brush Cap
55	65	91002640	Rear Cover
56	71	91003010	Auxiliary Handle Assy.
57	73	91002720	Switch
58	74	91002730	Cable Clamp
59	200	91002890	Stop Lever Assy.
60	201	91002900	Connecting Rod Assy.
61	202	91002910	Handle Assy.
62	203	91002920	auxiliary handle