




5154 ANGLE GRINDER 1500W



WATSON POWERTOOLS

5154 Angle Grinder 1500w

S.NO	Part No.	Spare Part Name	S.NO	Part No.	Spare Part Name
1	5154-001	External pressure plate	23	5154-023	Washer
2	5154-002	Inner pressure plate	24	5154-024	Rotor
3	5154-003	Grinding wheelcover	25	5154-025	Dust washer
4	5154-004	Output bearing	26	5154-026	607 Bearing
5	5154-005	Dust cover	27	5154-027	Bearing Cover
6	5154-006	Crossing head screw	28	5154-028	windshield Ring
7	5154-007	Front cover	29	5154-029	Crossing head screw
8	5154-008	6201 Bearing	30	5154-030	stator
9	5154-009	Clasp	31	5154-031	Encasement
10	5154-010	Big gear	32	5154-032	Carbon brush holder
11	5154-011	696 Bearing	33	5154-033	Crossing head screw
12	5154-012	Head cover	34	5154-034	Carbon brush
13	5154-013	Crossing head screw	35	5154-035	Coil spring
14	5154-014	O type washer	36	5154-036	Guard sleeve
15	5154-015	Self-locking pin	37	5154-037	Oower cable
16	5154-016	Self-locking cap	38	5154-038	Pressure plate
17	5154-017	Nut	39	5154-039	Crossing head screw
18	5154-018	Small gear	40	5154-040	Back cover
19	5154-019	608 Bearing	41	5154-041	Dust filter
20	5154-020	O type washer	42	5154-042	Switch
21	5154-021	Bearing plate	43	5154-043	Crossing head screw
22	5154-022	Crossing head screw			