




WATSON
PROFESSIONAL

5460 CUT OFF MACHINE 355MM



WATSON POWERTOOLS

5460 Cut off Machine 355mm

S.NO	Part No.	Spare Part Name	S.NO	Part No.	Spare Part Name
1	5460-001	Ball Bearing 6204W	35A	5460-035A	Pan Head Tapping Screw ST4x18.
2	5460-002	Woodruff Key	36	5460-036	Left Handle Set (With Item 40)
3	5460-003	Drive Spindle	37	5460-037	Nameplate
4	5460-004	Safety Guard	38	5460-038	Pan Head Screw M5x 10 (withSpring and Flat Washer)
5	5460-005	Flange	39	5460-039	Switch
6	5460-006	Pan Head Screw M5x52(with Spring and Flat Washer)	40	5460-040	Right Handle Set (With Item 36)
7	5460-007	Damper	41	5460-041	Pan Head Screw M5x52 (withSpring and Flat Washer)
8	5460-008	Washer	42	5460-042	Pan Head Screw M5x30 (withSpring and Flat Washer)
9	5460-009	Spring Washer	43	5460-043	Pan Head Screw M5 X 10 (withSpring and Flat Washer)
10	5460-010	Hex. Bolt M10x20	44	5460-044	Rear Cover
13	5460-013	Stator Assembly	45	5460-045	Hex. Socket Head PointlessScrew M5 x 8
14	5460-014	Pan Head Screw M5x80(with Spring and Flat Washer)	46	5460-046	Carbon Brush I-ff)lder
15	5460-015	Baffle Plate	47	5460-047	Carbon Brush
16	5460-016	Ball Bearing 6200ZZ	48	5460-048	Brush Holder Cap
17	5460-017	Rubber Pin	49	5460-049	Motor Housing
18	5460-018	Armature Assembly	50	5460-050	Chain Hook Pin
19	5460-019	Ball Bearing 6202-2Z	51	5460-051	Hex. Lock Nut M6
20	5460-020	O Ring	52	5460-052	Pan Head Tapping Screw ST4.2x16 (with Flat Washer)
21	5460-021	Wave Washer	53	5460-053	Strain Relief
22	5460-022	Gear Housing	54	5460-054	Insulation Washer
23	5460-023	Spindle Lock Pin	55	5460-055	Cord Guard
24	5460-024	Compression Spring	56	5460-056	Cord
25	5460-025	Lock Nut M5	57	5460-057	Hex. Nut M5
26	5460-026	Adjustable Guard	59	5460-059	Torsion Spring
27	5460-027	Bolt	60	5460-060	Base Assembly
29	5460-029	Rubber Pin	66	5460-066	Hex. Head Screw M16x170
30	5460-030	Ball Bearing 6000ZZ	67	5460-067	Washer
31	5460-031	Circlip for Shaft	68	5460-068	Pipe
32	5460-032	Gear	70	5460-070	Pan Head Screw M8 X 10
33	5460-033	Rubber Pin	71	5460-071	Spark Guard
34	5460-034	Gear Housing Cover	72	5460-072	Hex. Lock Nut M6
35	5460-035	Pan Head Tapping Screw ST4.2 X 22	73	5460-073	Hex. Lock Nut M16