


5560 JIGSAW MACHINE 650W



5560 Jigsaw Machine 85mm

S.NO	Part No.	Spare Part Name	S.NO	Part No.	Spare Part Name
1	5560-001	Screw ST4X55	41	5560-041	Screw ST4X16
2	5560-002	Screw ST4X14	42	5560-042	Handle Cover
3	5560-003	Copper cover	43	5560-043	Capacitance
4	5560-004	Front cover	44	5560-044	Switch
5	5560-005	Pin3X10	45	5560-045	Handle
6	5560-006	Stopper	46	5560-046	ScrewST4X18
7	5560-007	Plate Holder	47	5560-047	Pin5X25
8	5560-008	Fixture	48	5560-048	Pin3X10
9	5560-009	Plate	49	5560-049	Pin6X25
10	5560-010	Screw ST4X10	50	5560-050	Balance lever
11	5560-011	Paper washer	51	5560-051	Spring
12	5560-012	Snao spring $\varnothing 8$	52	5560-052	Split Ring Q 7
13	5560-013	Transmission Wheel	53	5560-053	Round Head Screw
14	5560-014	Pin5X10	54	5560-054	Ball
15	5560-015	Washer $\varnothing 8$	55	5560-055	Gear Housing
16	5560-016	Balance Plate	56	5560-056	Washer 08
17	5560-017	Rocking Plate	57	5560-057	Bearing608
18	5560-018	Needle Bearing HK0810	58	5560-058	Wind Guard
19	5560-019	Bevel Gear	59	5560-059	Rotor
20	5560-020	Washer 08	60	5560-060	Bearing607
21	5560-021	Gear Shaft	61	5560-061	Shock block ring
22	5560-022	Pin3X22	62	5560-062	Stator
23	5560-023	PIN 4X11. 5	63	5560-063	Motor Housing
24	5560-024	Roller Wheel	64	5560-064	ScrewST4X14
25	5560-025	Roller Wheel Holder	65	5560-065	Cord Flange
26	5560-026	Split Washer $\varnothing 4$	66	5560-066	Spring
27	5560-027	Spring	67	5560-067	Carbon Brush
28	5560-028	Oil Seal	68	5560-068	Brush Holder
29	5560-029	Needle Bearing HK061208	69	5560-069	Cord Cover
30	5560-030	Screw MX8	70	5560-070	Power Cord
31	5560-031	PIN6X15	71	5560-071	Tapping Screw
32	5560-032	Copper cover	72	5560-072	Brush Cover
33	5560-033	Seal Ring	73	5560-073	Screw ST4X28
34	5560-034	Seal Washer	74	5560-074	Rear Cover
35	5560-035	Snap Spring $\varnothing 16$	75	5560-075	Name Plate
36	5560-036	Reciprocating Lever			
37	5560-037	Saw blade			
38	5560-038	Bottom Board			
39	5560-039	Plate Pinch			
40	5560-040	Screw M6X20			