




6110B Diamond Core Drill/110mm/1400W



RISHAB INTERNATIONAL

6110 B DIAMOND CORE DRILL /110 MM

S.No.	Drawing No.	Part No	Description
1	1	1331060	Spindle
2	2	3360160	Oil Seal
3	2	3360160	Oil Seal
4	3	1600630	Seal Sleeve
5	4	3370390	Washer
6	5	6240280	Water Tap Assy.
7	6	1621060	Gearbox
8	7	2111010	Bearing
9	7	2111010	Bearing
10	7	2111010	Bearing
11	8	1361050	Gear Shaft
12	9	2760010	Key
13	10	1361061	Gearwheel I
14	11	2111590	Bearing
15	12	2430070	Wave Washer
16	13	2510060	Retainer Ring
17	14	1820690	Bearing Sleeve
18	15	1141360	Washer
19	15	1141360	Washer
20	16	1710180	Friction Plate
21	16	1710180	Friction Plate
22	17	1820700	Gear Sleeve
23	18	1361070	Big Gear II
24	19	1550060	Spring
25	20	2630120	Nut
26	21	3420370	Washer
27	22	1630500	Medial Flange
28	23	2110920	Bearing
29	24	1141370	Washer
30	25	4421681	Armature
31	26	1140130	Steel Washer
32	27	2112200	Bearing
33	28	2430180	Wave Washer
34	29	3210780	Wind Deflector
35	30	2210440	Tapping Screw
36	31	4411650	Coil
37	32	3131490	Motor Shell
38	34	1680190	Rear Cap
39	35	2211180	Tapping Screw
40	36	2300330	Washer Assy.
41	37	3380460	Scraper Seal
42	38	432001A0	Brush Holder
43	39	4311280	Carbon Brush Assy.
44	40	433002A0	Brush Cap
45	41	3141590	Right Handle
46	42	2210230	Tapping Screw
47	42	2210230	Tapping Screw
48	43	2220020	Tapping Screw
49	43	2220020	Tapping Screw
50	44	3180060	Cable Clamp
51	45	3320061	Cable Sleeve
52	46	4110290	Power Cord
53	47	4470310	Switch
54	48	3141580	Left Handle
55	49	3141600	Front Holder
56	50	2211190	Screw
57	51	3141610	Holder Seat
58	53	1540310	Torsional Spring
59	55	2350010	Socket Head Cap Screw
60	56	3300240	Holder Seat
61	57	6240290	Water Faucet
62	58	6240300	Water Pipe
63	59	6270550	Auxiliary Handle
64	60	2340270	Hex Bolt
65	61	6200870	Sleeve
66	201	7137720	Gear Assy.
67	202	7121530	Handle Assy.
68	203	6270750	Auxiliary Handle Assy.