




**WATSON**  
INDUSTRIAL

# 3123 ANGLE GRINDER 1050W INDUSTRIAL (S.S)



**WATSON POWER TOOLS**

<b>3123 Angle Grinder IOS0w Industrial (S.S)</b>			
<b>S.NO</b>	<b>PART NO.</b>	<b>SPARE PART NAME</b>	<b>QTY</b>
1	3123-001	outer flange	1
2	3123-002	Inner flange	1
3	3123-003	wheel guard	1
4	3123-004	Screw M4x13	4
5	3123-005	Dustproof cover	1
6	3123-006	output spindle	1
7	3123-007	front cover	1
8	3123-008	O ring D 46x \$1	1
9	3123-009	Bearing 6201	1
10	3123-010	\$32 Circlip for hole	1
11	3123-011	Gear	1
12	3123-012	Needle bearing HK0709	1
13	3123-013	Screw ST4x28	4
14	3123-014	Self-locking cap	1
15	3123-015	Self-locking spring	1
16	3123-016	O ring 66x\$ 1	1
17	3123-017	Self-locking pin	1
18	3123-018	Gear box	1
19	3123-019	M6 nut	1
20	3123-020	pinion	1
21	3123-021	Bearing spacer	1
22	3123-022	Bearing 608	1
23	3123-023	ring A \$29.4x0.75	1
24	3123-024	Middle cover	1
25	3123-025	Rotor	1
26	3123-026	Dustproof ring	1
27	3123-027	Bearing spacer	1
28	3123-028	Bearing 607	1
29	3123-029	Bearing cover	1
30	3123-030	Windshield	1
31	3123-031	Screw ST4x75	2
32	3123-032	Stator	1
33	3123-033	Housing	1
34	3123-034	Insulating sheet	2
35	3123-035	Screw ST3x7. 5	4
36	3123-036	Carbon brush	2
37	3123-037	Carbon brush holder	2
38	3123-038"	Coil spring	2
39	3123-039	Push block	1
40	3123-040	Putter	1
41	3123-041	Rear cover	1
42	3123-042	Screw ST4x14	1
43	3123-043	Side cover	2
44	3123-044	Capacitance	1
45	3123-045	Switch	1
46	3123-046	Cable clamp	1
47	3123-047	Cable	1
48	3123-048	Screw ST4x14	2
49	3123-049	Crimping Plate	1
50	3123-050		