




**WATSON**  
INDUSTRIAL

# 3225 MARBLE CUTTER CM5 INDUSTRIAL



**WATSON** **POWERTOOLS**

<b>3225 Marble Cutter CM5 Industrial</b>			
<b>S.NO</b>	<b>PART NO.</b>	<b>SPARE PART NAME</b>	<b>QTY</b>
1	3225-001	Screw M5X30	3
2	3225-002	Screw ST4X16	4
3	3225-003	brush cover	2
4	3225-004	Screw SR4X14	4
5	3225-005	SPRING FOR BRUSH	2
6	3225-006	CARBON BRUSH	2
7	3225-007	BRUSH HOLDER	2
8	3225-008	RIGHT COVER	1
9	3225-009	SCREW ST4X8	2
10	3225-010	FILTER NET	1
11	3225-011	LEFT COVER	1
12	3225-012	CABLE	1
13	3225-013	CABLE PROTECTOR	1
14	3225-014	SWITCH SLEVE	1
15	3225-015	SWITCH	1
16	3225-016	LOCK BUTTON	1
17	3225-017	ELECTRIC CAPACITY	1
18	3225-018	HANDLE COVER	1
19	3225-019	SCREW ST4X10	2
20	3225-020	HOUSING	1
21	3225-021	CABLE FIXTURE	1
22	3225-022	STATOR	1
23	3225-023	SCREW ST4X70	2
24	3225-024	WINDSHIELD	1
25	3225-025	BEARING SLEEVE FOR 608	1
26	3225-026	BEARING 608	1
27	3225-027	SPACER (018X08.2X0	1
28	3225-028	DUST PROOF RING	1
29	3225-029	ARMATURE	1
30	3225-030	PAD FOR BEARING 629 (020X09.1X0.2)	1
31	3225-031	BEARING 629	1
32	3225-032	O Ring (025.7x02)	1
33	3225-033	PINION	1
34	3225-034	M7 NUT	1
35	3225-035	SPRING 09	1
36	3225-036	DEPTH ADJUSTING SPANNER	1
37	3225-037	NUT M6X17	1
38	3225-038	PAD (016X06.5X1.5)	1
39	3225-039	WATER FAUCET	1
40	3225-040	SCREW M4X13	1
41	3225-041	SCREW M6X25	1
42	3225-042	GEAR BOX	1
43	3225-043	BEARING 688	1
44	3225-044	CIRCLE 012 FOR AXIS	1
45	3225-045	BIG GEAR	1
46	3225-046	CIRCLE 032 FOR HOLE	1
47	3225-047	BEARING 6201	1
48	3225-048	SPINDLE	1
49	3225-049	WOODRUFF KEY 4X13	1
50	3225-050	PAD	1
51	3225-051	FRONT COVER	1
52	3225-052	SCREW M5X22	2
53	3225-053	OIL SEAL	1
54	3225-054	OUTER FLANGE	1
55	3225-055	INNER FLANGE	1
56	3225-056	SCREW M8X22(LEFT)	1
57	3225-057	06X40 HEAD SCREW M5	1
58	3225-058	BASE SET	1
59	3225-059	NUT M5	1
60	3225-060	SOCKET SPANNER	1
61	3225-061	WRENCH	1