




WATSON
PROFESSIONAL

5154 ANGLE GRINDER 1500W



WATSON POWERTOOLS

5154 Angle Grinder 1500w

S.NO	PART NO.	SPARE PART NAME
1	5054-001	External Pressure Plate
2	5054-002	Inner Pressure Plate
3	5054-003	Grinding wheelcover
4	5054-004	Output bearing
5	5054-005	Dust cover
6	5054-006	Crossing head screw
7	5054-007	Front cover
8	5054-008	6201 Bearing
9	5054-009	Clasp
10	5054-010	Big gear
11	5054-011	696 Bearing
12	5054-012	Head cover
13	5054-013	Crossing head screw
14	5054-014	O type washer
15	5054-015	Self -locking pin
16	5054-016	Self -locking cap
17	5054-017	Nut
18	5054-018	Small gear
19	5054-019	608 Bearing
20	5054-020	O type washer
21	5054-021	Bearing Plate
22	5054-022	Crossing head screw
23	5054-023	washer
24	5054-024	Rotor
25	5054-025	Dust washer
26	5054-026	607 Bearing
27	5054-027	Bearing covert
28	5054-028	Windshield screw
29	5054-029	Crossing head screw
30	5054-030	Stator
31	5054-031	Encasement
32	5054-032	Carbon brush holder
33	5054-033	Crossing head screw
34	5054-034	Carbon brush
35	5054-035	Coil spring
36	5054-036	Guard sleeve
37	5054-037	Oower cable
38	5054-038	Pressure plate
39	5054-039	Crossing head screw
40	5054-040	Back cover
41	5054-041	Dust filter
42	5054-042	switch
43	5054-043	Crossing head screw