




WATSON
PROFESSIONAL

5355 DEMOLITION HAMMER (23KG)



WATSON POWER TOOLS

5355 Demolition Hammer 30 mm(23kgs)

S.NO	PART NO.	SPARE PART NAME			
			49	5355-0049	bearing board
1	5355-001	locking bar	50	5355-0050	washer
2	5355-002	round pin 5*32	51	5355-0051	bearing 6203-2RS
3	5355-003	O ring 18*8	52	5355-0052	nut M8
4	5355-004	headstrong	53	5355-0053	handle seat
5	5355-005	lock lever set	54	5355-0054	washer
6	5355-006	lock lever spring	55	5355-0055	anti-vibration spring
7	5355-007	lock lever washer	56	5355-0056	anti-vibration board
8	5355-008	screw M10*55	57	5355-0057	anti-vibration screw
9	5355-009	washer 10	58	5355-0058	anti-vibration sleeve
10	5355-0010	headstrong spring	59	5355-0059	screwM5*16
11	5355-0011	O ring 60*2.3	60	5355-0060	anti-vibration spring
12	5355-0012	hammer rod set	61	5355-0061	screw ST4.8*18
13	5355-0013	impact hammer rod	62	5355-0062	right handle
14	5355-0014	anti-vibration ring47.5*66.5*14.3	63	5355-0063	screw ST3.9*16
15	5355-0015	O ring 26.7*3.4	64	5355-0064	cable board
16	5355-0016	aluminium opening set	65	5355-0065	capacitance
17	5355-0017	opening set	66	5355-0066	left handle
18	5355-0018	opening set ring	67	5355-0067	switch
19	5355-0019	big washer	68	5355-0068	rotor
20	5355-0020	anti-vibration ring58*68*9.3	69	5355-0069	washer
21	5355-0021	cylinder case	70	5355-0070	screw \ST4.8*65
22	5355-0022	screw M8*40	71	5355-0071	fan guide
23	5355-0023	cylinder	72	5355-0072	stator
24	5355-0024	seal ring	73	5355-0073	spring
25	5355-0025	piston pin 12*43.5	74	5355-0074	glass sleeve
26	5355-0026	piston	75	5355-0075	motor case
27	5355-0027	connecting rod	76	5355-0076	carbon brush
28	5355-0028	needling bearing	77	5355-0077	screw \ST3.9*12
29	5355-0029	needling bearing board	78	5355-0078	spring
30	5355-0030	washer 8	79	5355-0079	brush holder
31	5355-0031	screw M8*30	80	5355-0080	screw M5*35
32	5355-0032	eccentric shaft	81	5355-0081	cable
33	5355-0033	aluminium motor case	82	5355-0082	cable cover
34	5355-0034	seal ring	83	5355-0083	screw M5*45
35	5355-0035	bearing \6205-RS	84	5355-0084	back cover
36	5355-0036	bearing board	85	5355-0085	oil seal
37	5355-0037	screw M5*22	86	5355-0086	oil champ
38	5355-0038	ring 22.5*34*7.5	87	5355-0087	washer
39	5355-0039	big gear	88	5355-0088	oil cover
40	5355-0040	semi-round key	89	5355-0089	O ring
41	5355-0041	ring 22 5355-041	90	5355-0090	oil nut
42	5355-0042	bearing \6302-RS	91	5355-0091	knob
43	5355-0043	front cover	92	5355-0092	auxiliary handle
44	5355-0044	screw M6*25	93	5355-0093	knob blot
45	5355-0045	bearing 6201-2RS	94	5355-0094	handle fixed block
46	5355-0046	middle gear	95	5355-0095	steel sleeve
47	5355-0047	screw M6x14	96	5355-0096	piston pin
48	5355-0048	bearing 6001-2RS			